ICHNOS: TROUBLESHOOTING MANUAL & PROTOCOL OPTIMIZATION GUIDE



TABLE OF CONTENTS

01	Introduction & Foundational Rationale	1
02	Academic & Technical Advisory Board	1
03	Technical Troubleshooting & Experimental Safety Manual	3
3.1	PCR & Colony PCR	3
3.2	Genome Integration Failure Analysis	5
3.3	Quantitative Real-Time PCR (qPCR) & RT-qPCR	8
3.4	Advanced Fluorescence Microscopy & Imaging Diagnostics	9

ICHNOS: Troubleshooting Manual & Protocol Optimization Guide

A foundational resource for current and future iGEM teams, designed to facilitate troubleshooting, promote experimental reproducibility, and elevate research standards within Foundational Advance.

1. Introduction & Foundational Rationale

This Troubleshooting Manual serves as a companion guide to the experimental procedures carried out during the execution of the Proof of Concept (PoC) for project ICHNOS. Given the fast-paced and highly demanding nature of the iGEM Competition, we recognized the imperative need to pre-emptively identify potential experimental pitfalls, interpret sub-optimal outcomes, and establish systematic protocols to avoid recurring errors prior to wet lab execution.

Synthesized from the hands-on experience of our Wet Lab team and enriched through consults with domain-expert advisors, this manual establishes our team's operational framework for experimental troubleshooting across key techniques: PCR, Colony PCR, RT-qPCR, Genomic Integration, and Advanced Microscopy/Imaging.

In this manual, there is no specific range of numbers, concentrations, temperatures or other metrics. The reason behind it is that we did not want to tailor it to our experimental process and project specificities, rather keep it open and flexible for any experimental situation or circumstance.

Our long-term ambition for this initiative is twofold:

Internal Legacy: To continuously expand and complete this manual for additional methodologies as our project evolves.

Community Legacy (iGEM Tradition): To institute an open-access, evolving wiki reference that future iGEM teams can adopt, enrich, and customize for their own experimental pipelines, thereby optimizing protocols and streamlining troubleshooting across the Synthetic Biology community.

2. Academic & Technical Advisory Board

We extend our deepest gratitude to the academic specialists whose expert consultation provided invaluable insights into protocol troubleshooting and analytical interpretation:

Assoc. Prof. Myrto Denaxa

Affiliation: Associate Professor, Department of Physiology, School of Medicine, University of Patras; Affiliated Researcher, Biomedical Sciences Research Center (BSRC) "Alexander Fleming".

Research Focus: Dr. Denaxa's research focuses on the developmental neurobiology of cortical interneurons, cell fate specification, migration, and circuit integration. Her methodological background in high-resolution confocal microscopy, fluorescence signal calibration, and live-cell imaging guided our protocol optimization for reducing background noise and autofluorescence in imaging assays.

Dr. Helene Martin-Yken

Affiliation: Senior Scientist, National Research Institute for Agriculture, Food and Environment (INRAE), Toulouse Biotechnology Institute (TBI); Hosted Researcher at LAAS-CNRS, Toulouse.

Research Focus: A specialist in fungal morphogenesis, yeast cell wall signaling cascades, and synthetic biology. Her ongoing work focuses on utilizing Saccharomyces cerevisiae as a chassis for constructing cell-based biosensors and engineering metabolic pathways. Her insights guided our genomic integration design and host-strain selection in yeast.

Dr. Fivos Borbolis

Affiliation: Assistant Professor, Department of Biology, University of Patras.

Research Focus: Dr. Borbolis's research investigates cellular stress responses, mitochondrial dynamics, and selective autophagy specifically mitophagy using the model organism Caenorhabditis elegans (C. elegans). His specialized knowledge in cellular homeostasis and stress-induced organelle degradation provided the foundation for analyzing dose-response kinetics and reporter stability under physiological stress.

Prof. Dimitris Vlastos

Affiliation: Department of Biology, Division of Genetics, Cell & Developmental Biology, University of Patras.

Research Focus: Specialist in molecular genetics, DNA integrity, genotoxicity, and nucleic acid reaction conditions. His technical expertise was instrumental in troubleshooting PCR amplification issues, resolving non-specific band formation, and optimizing primer binding stringency.

Dr. Eirini Griela

Affiliation: Research Associate / Postdoctoral Researcher, Agricultural University of Athens (AUA).

Research Focus: Dr. Griela specializes in transcriptomics, gene expression profiling, and molecular diagnostic assays using quantitative real-time PCR (RT-qPCR). Her input was essential for standardizing our RT-qPCR workflow, baseline thresholds, and sample preparation protocols to avoid enzyme inhibition.

Dr. Vasiliki Adamopoulou

Affiliation: Postdoctoral Researcher, Department of Chemistry, University of Patras.

Research Focus: Dr. Adamopoulou's research focuses on synthetic organic chemistry, analytical characterization, and biochemical isolation of functional biomolecules. Her advice was central to

the standardisation of chemical preparation steps and handling reaction buffer components in our experimental setups.

3. Technical Troubleshooting & Experimental Safety Manual

3.1 Polymerase Chain Reaction (PCR) & Colony PCR

The Polymerase Chain Reaction (PCR) serves as a foundational tool in synthetic biology and diagnostics. Operational failures in amplification not only impede workflow progress but can also lead to the misinterpretation of genetic constructs, raising functional safety and quality assurance concerns.

3.1.1 Symptom 1: Complete Loss of Amplification (Blank Gel)

Primary Cause Template Impurities & Carryover Inhibitors

- **Mechanism:** Co-extraction of cellular debris, residual salts, ethanol, phenolic compounds, or SDS directly inhibits DNA polymerase activity or chelates required divalent cations (Mg2+).
- **Safety & Quality Impact:** Incomplete or compromised assays can result in false-negative target detection, impacting downstream biosafety verifications.
- **Remediation Protocol:**
    - Perform serial dilutions of the DNA template (e.g., 1:10, 1:50, 1:100) to reduce inhibitor concentrations below effective operational thresholds.
    - Re-purify the template DNA using silica-spin column protocols or standard ethanol/isopropanol precipitation.

Sub-optimal Annealing Temperature

- **Mechanism:** Excessive thermal stringency during the annealing phase prevents primer-template hybridization.
- **Remediation Protocol:**
    - Lower the annealing temperature in decrements.
    - Execute a temperature gradient PCR across a range to empirically determine optimal binding kinetics.

Insufficient Kinetics (Extension/Annealing Durations)

- **Mechanism:** Inadequate dwell time prevents full-length target strand synthesis or stable primer attachment.
- **Remediation Protocol:**
    - Extend annealing duration beyond 20 seconds.
    - Calibrate extension duration to match polymerase processing speed for high-fidelity polymerases.

Reagent Stoichiometry & Reaction Buffer Balance

- **Mechanism:** Sub-optimal ion concentrations compromise enzyme turnover and complex stability.
- **Remediation Protocol:**
    - Adjust final primer concentration.
    - Optimize $MgCl_2$ concentrations within the master mix to stabilize primer-template complexes.
    - Transition to optimized buffer formulations or high-fidelity enzyme systems.

3.1.2 Symptom 2: Non-Specific Amplification & Smearing

Low-Stringency Annealing Conditions

- **Mechanism:** Excessively permissive temperature allows off-target primer binding across partial homology sites.
- **Remediation Protocol:**
    - Increase annealing temperature to enforce sequence-specific hybridization.
    - Reduce annealing dwell time to minimize non-specific association.

Mispriming & Secondary Structure Dynamics

- **Mechanism:** Formation of stable primer-dimers or intramolecular hairpins depletes active reagents and yields spurious amplicons.
- **Remediation Protocol:**
    - Conduct *in silico* bioinformatic evaluation prior to *in vitro* execution using computational design tools (e.g., Benchling, Primer3).
    - Verify thermodynamic parameters for self-dimer and cross-dimer formation.
    - Target a balanced GC content and eliminate 3' end complementarity.

Polymerase Fidelity & Non-Specific Pre-Cycling Activity

- **Mechanism:** Non-proofreading polymerases lacking 3' to 5' exonuclease activity increase misincorporation rates. Pre-cycling room-temperature assembly promotes non-specific extension.
- **Remediation Protocol:**
    - Substitute standard *Taq* with high-fidelity, proofreading enzymes (e.g., Q5, Phusion, KAPA HiFi).
    - Utilize Hot-Start polymerase formulations to inhibit low-temperature enzymatic activity during reaction setup.

3.1.3 Special Considerations for Colony PCR Diagnostics

Mechanism & Pitfalls: Direct amplification from intact yeast or bacterial cells often releases cellular debris and polysaccharides that inhibit DNA polymerase. In yeast, incomplete cell wall lysis causes target DNA to remain inaccessible, leading to false-negative results. Additionally, picking an excessively large colony introduces heavy template overload and carryover medium contaminants, causing severe reaction inhibition or non-specific smearing.

3.2: Genome Integration Failure Analysis (Lithium Acetate & Homologous Recombination)

In general, it is safe to say that genomic integration with Lithium Acetate offers an almost fool-proof integration method with high success rates and it is not suggested to modify it extensively . So the following advice stretches on the revision of smaller mistakes and not fundamental experimental alterations.

3.2.1 Symptom 1: Complete Absence of Transformants (Zero Colonies on Selective Plates)

Sub-optimal Competence & Physiological State of Host Cells

- **Mechanism:** Harvesting yeast cells outside the mid-logarithmic growth phase ($OD_{600} < 0.6$ or > 1.0) drastically reduces cell wall permeability and competence. Cells entering the stationary phase develop thickened cell walls that resist PEG/LiAc-mediated DNA uptake.
- **Safety & Quality Impact:** Total transformation failure halts biological assembly pipelines and delays experimental verification of bio-contained constructs.
- **Remediation Protocol:**
    - Strictly monitor cell density and harvest host cultures at mid-log phase ($OD_{600} = 0.6–0.8$).
    - Refresh overnight cultures by diluting $1:100$ in fresh, rich media (YPD) and allow $4–6 hours$ of active outgrowth at 30°C prior to transformation.

Ineffective Heat Shock Kinetics & Thermal Lethality

- **Mechanism:** Insufficient thermal energy fails to permeabilize the plasma membrane, preventing cassette entry. Conversely, overexposure to elevated temperatures or prolonged duration) causes irreversible protein denaturation and high cell mortality.
- **Remediation Protocol:**
    - Calibrate water baths to precisely 42°C using external digital thermometers.
    - Limit heat shock duration strictly to 15 minutes for standard *S. cerevisiae* protocols.
    - Gently handle post-heat shock cells to avoid mechanical lysis.

Incomplete Carrier DNA Denaturation & Degradation

- **Mechanism:** Failure to fully denature single-stranded carrier DNA (ssDNA) prevents it from binding to and protecting target DNA fragments against native cytosolic nucleases, resulting in target cassette degradation.
- **Remediation Protocol:**
    - Boil carrier ssDNA at 95°C for 5 minutes immediately before addition to the transformation mix.
    - Snap-cool on ice for at least 2 minutes to prevent re-annealing into double-stranded structures.

Selection Medium Incompatibility & Marker Mismatch

- **Mechanism:** Plating transformed cells on incorrect auxotrophic dropout media (e.g., missing essential amino acids not covered by the selection marker) or improper antibiotic concentrations prevents cell survival regardless of successful integration.
- **Remediation Protocol:**
    - Cross-verify host strain auxotrophies against the transformation marker gene (e.g., *HIS3*, *URA3*, *LEU2*).
    - Include a positive control (plating mock-transformed cells on non-selective YPD) to confirm cell viability post-heat shock.

3.2.2 Symptom 2: High Background & False-Positive Transformation (Lawn Growth or Non-Integrated Colonies)

Insufficient Wash Steps & Nutrient Carryover

- **Mechanism:** Residual growth media (e.g., YPD) or extracellular nutrients carried over into selective plates allow non-transformed, auxotrophic host cells to undergo background divisions and form micro-colonies.
- **Remediation Protocol:**
    - Perform thorough cell washes using sterile $100mM$ Lithium Acetate or sterile ddH_2O prior to final resuspension.
    - Ensure total removal of supernatant following post-heat shock centrifugations.

Episomal Persistence & Non-Homologous End Joining (NHEJ)

- **Mechanism:** Linear DNA fragments with insufficient homology arm lengths or structural instability can persist episomally or integrate off-target via non-homologous recombination, producing false-positive marker expression without true genomic integration.
- **Safety & Quality Impact:** Off-target integration or episomal retention compromises genetic stability, alters expression dynamics, and invalidates biosafety characterization.
- **Remediation Protocol:**
    - Design homology arms with a minimum length of $50–80bp$ strictly specific to the target genomic locus.
    - Perform high-stringency diagnostic locus-specific junction PCR (using one primer annealing outside the homology arm in the native genome and one inside the inserted cassette) to confirm locus-specific integration.

Low Equimolar Stoichiometry in Multi-Fragment Assemblies

- **Mechanism:** Unequal molar ratios of transforming DNA fragments lead to incomplete locus assembly, resulting in truncation, background recombination, or selective pressure favoring partial integration events.
- **Remediation Protocol:**
    - Quantify DNA fragment concentrations accurately using spectrophotometric or fluorometric assays.
    - Pool linear fragments at strict equimolar ratios rather than equal mass ratios

3.3 Quantitative Real-Time PCR (qPCR) & RT-qPCR Safety Integration

Quantitative PCR (qPCR) and Reverse Transcription qPCR (RT-qPCR) represent essential analytical frameworks for evaluating genetic expression dynamics. Due to extreme sensitivity, minor procedural variances can lead to substantial analytical errors, false quantifications, or hazardous biological misclassifications. The following paragraphs provide partial explanation to common mistakes and useful extra steps that later prevent future mistakes or help explaining the results.

Most common unexpected RT-qPCR results should be evaluated systematically:

I. No amplification or unexpectedly late C_t: assess template quality, RNA/cDNA integrity, possible inhibition, reaction preparation, and assay performance.

II. Large variation between technical replicates: evaluate pipetting consistency, mixing, reaction setup, bubbles, and sample homogeneity.
III. Amplification in the NTC: investigate possible reagent or environmental contamination and nonspecific amplification/primer-dimer formation.
IV. Amplification in the –RT control: investigate genomic-DNA contamination.
V. Multiple melting peaks or abnormal melting profiles: investigate nonspecific amplification or primer-dimer formation.
VI. Unexpected differences between biological samples: confirm RNA quality, normalization strategy, reference-gene stability, assay efficiency, and biological controls before attributing the difference to altered gene expression.

3.3.1 Biosafety, Contamination Prevention

- **RNA Quality Assessment:**
  - Prior to cDNA synthesis, evaluate total RNA purity via spectrophotometry.
  - Ensure the A260/A280 ratio strictly exceeds 2 (indicative of pure RNA devoid of protein contamination).
  - Monitor the A260/A230 ratio to verify low organic compound and salt carryover.
  - Estimate total RNA integrity and concentration via denaturing agarose gel electrophoresis before proceeding to downstream steps.
- **Aseptic Technique & Environmental Containment:**
  - Maintain strict RNase-free environment standards (designated sterile laminar flow hoods, certified RNase/DNase-free filter tips, and periodic surface decontamination with RNase-deactivating agents).
  - Prevent foreign DNA/cDNA cross-contamination, which poses severe risks of false-positive gene detection.

3.2.2 Precision Pipetting & Reaction Optimization

- **Aliquoting Mechanics:**
  - Handle micro-volumes with high-precision, calibrated pipettes. Ensure total reaction volumes and master mix ratios are strictly preserved.
  - Utilize narrow-bore, low-retention filter tips to maximize fluid transfer accuracy during cDNA loading.
  - Perform brief, thorough centrifugation steps to collect liquid at the bottom of reaction wells and eliminate trapped micro-bubbles that interfere with fluorescence acquisition.

3.2.3 Computational Validation & Experimental Controls for Data Integrity

To prevent inaccurate transcription rate analyses and unnecessary re-runs, the following control system architecture should be integrated.

I. **In Silico Pre-Validation:** Screen all primer sets computationally prior to synthesis to prevent *in vitro* secondary structures and non-specific binding.
II. **Primer-Only Background Assay:** Run a parallel negative control assay containing only primer pairs (without cDNA template). Use these fluorescence amplification values as a mathematical baseline subtraction factor during data post-processing.
III. **Untransformed Host Control (Wild-Type Baseline):** Run a benchmark assay using mRNA isolated from wild-type host cells (e.g., untransformed yeast lacking the integrated genetic cassette). This calibration control isolates endogenous transcription kinetics from heterologous insert dynamics, ensuring experimental safety and accurate functional characterization.

3.4 Advanced Fluorescence Microscopy & Imaging Diagnostics

High-resolution fluorescence microscopy allows visual verification of synthetic genetic systems, localization of fusion proteins, and structural biosafety analyses.

3.4.1 Symptom 1: Elevating Background Noise & Autofluorescence

Substrate & Media Interference

- **Mechanism:** Standard polystyrene multi-well plates and complex culture media (e.g., YPD, rich synthetic media, riboflavin-rich reagents) emit native fluorescence, reducing signal-to-noise ratios.
- **Remediation Protocol:**
    - Replace plasticware with optically clear, glass-bottom dishes or imaging plates.
    - Wash and transition cells into low-autofluorescence media (e.g., Synthetic Complete lacking riboflavin and folic acid, or sterile PBS hardware prior to image acquisition.

Systemic Controls for Chemical Perturbations

- **Mechanism:** Exposures to specific chemical stress agents (e.g., DTT, H_2O_2) alter intracellular redox states, causing intrinsic baseline fluorescence shifts.
- **Remediation Protocol:**
    - Always acquire image series for non-labeled, wild-type (WT) reference strains subjected to identical chemical exposures.
    - Map baseline fluorescence shifts to ensure observed signals reflect genuine reporter activity rather than native cellular stress responses.

Essential Experimental Controls for Imaging Diagnostics

To ensure rigorous validation of reporter specificity, quantify signal-to-noise ratios, and eliminate optical or chemical artifacts, the following controls must be run in parallel with every experimental imaging assay:

- **Control 1: Media-Only Control (Substrate Baseline)**
    - **Composition:** Low-autofluorescence imaging media without cells or chemical reagents.
    - **Purpose:** Establishes the baseline fluorescence of the culture vessel, glass bottom, and liquid medium, ensuring no optical interference from reagents or plasticware.
- **Control 2: Uninduced Integrated Strain (Basal Expression / System Leakiness)**
    - **Composition:** Host strain transformed with the full genetic cassette, grown in the **absence** of the specific inducer/stress agent.
    - **Purpose:** Measures promoter leakiness and basal reporter expression in a physiological state.
- **Control 3: Induced Wild-Type Strain (Chemical & Cellular Autofluorescence)**
    - **Composition:** Untransformed wild-type (WT) host strain (lacking the genetic cassette) exposed to the **highest concentration** of the inducer/stress agent.
    - **Purpose:** Quantifies cellular autofluorescence induced by chemical stress and verifies that the inducer alone does not generate false-positive fluorescent signals.
- **Control 4: Cross-Induction / Non-Target Specificity Control (Orthogonality Verification)**
    - **Composition:** Strain transformed with the targeted genetic cassette, exposed to a **non-specific / non-target inducer** (e.g. testing an oxidative stress strain with a copper inducer or ER stress agent).
    - **Purpose:** Demonstrates promoter specificity and confirms that the reporter system is not non-specifically activated by general cellular stress or off-target chemical triggers.

3.4.2 Symptom 2: Dynamic Range Anomalies (Saturation & Under-Exposure)

Dynamic Range Calibration

- **Mechanism:** Pixel intensity overflow or signal truncation skews quantitative expression measurements.
- **Remediation Protocol:**
    - Monitor active intensity histograms during acquisition.
    - Adjust exposure duration and light source power (LED/Laser) to keep peak signals within the linear dynamic range (approx 70–80 of maximum bit depth), completely avoiding saturated pixels.

Reporter Kinetics & Maturation Dynamics

- **Mechanism:** Fluorophore signal decay or delayed chromophore maturation times yield misleading temporal localization profiles.
- **Remediation Protocol:**
    - Account for fluorophore half-life and maturation kinetics (e.g., comparing fast-folding GFP variants vs. slower-maturing mCherry) when determining post-induction imaging time-points.

3.4.3 Symptom 3: Multi-Channel Cross-Talk & Hardware Variability

Spectral Bleed-Through

- **Mechanism:** Overlapping emission spectra between channels (e.g., GFP and mCherry) lead to false co-localization artifacts.
- **Remediation Protocol:**
    - Execute sequential channel acquisition protocols rather than simultaneous illumination.
    - Utilize narrow-band pass filters precisely matched to fluorophore excitation/emission peaks.

Metadata Standardization & Environmental Reproducibility

- **Mechanism:** Unrecorded or inconsistent hardware parameters prevent inter-assay comparisons and compromise experimental reproducibility.
- **Remediation Protocol:**
    - Systematically document hardware parameters across biological replicates: microscope model, objective numerical aperture (NA), magnification (20 times, 40 times, 100 times oil immersion), laser power, gain, exposure, and software settings.
    - Maintain uniform cell density across single-layer fields of view to preserve light path consistency.